

Introducing the *NEW* Insulation Snakes Buckle



Our new innovative buckle design can be found on the following Cobra Tan and Original Black Products:

- Sidewinders: 06" to 24" wide
- Inline Hoods: up to 24" wide
- Riser Hoods: up to 24" wide
- PLLC's: Plunger Lift Lubricator Covers
- SNB's: Snake Bites up to 24" wide
- PIG's: up to 24" wide
- ProSnakes: PS1220-4

Best Wrap For The Cold Snap!

*5 Easy Steps to using our new buckle



Step 1:

Partially open buckle.



Step 2:

Insert angled end of strap through buckle opening.

Our Support Team would love to answer any product questions you might have!



Step 3:

Holding buckle steady with one hand, pull strap through until proper tightness is achieved.



Step 4:

Close buckle, locking strap into place.



Step 5:

It is important not to **over-tighten** the strap as this will cause a loss of R-Value.